


SmartCard-8




User Manual

GTEK[®], INC.



Congratulations!

You've purchased the most advanced intelligent multiport serial card available on the market today! Your SmartCard-8 will provide you with years of efficient and trouble free service. The installation of the SmartCard-8 is not difficult. However you must install the SmartCard-8 correctly to ensure optimum performance. Therefore, before installing your SmartCard-8, please thoroughly read this instruction manual.



CAUTION

Be sure that the power switch on your computer is turned off and the power cord is removed from your computer before installing or removing any equipment.

Installation

Before installing your SmartCard-8, you must configure the base address and interrupt selection for the card. The factory default configuration is Base Address 2E0h and no interrupt selected.

Selecting a Base Address

Each SmartCard-8 that you install occupies 4 bytes of I/O space. You must select a 4 byte region of I/O which is not utilized by another I/O device. The chart below illustrates what types of devices use I/O space and at what address they may be located.

Hex Range

100 - 107 PS/2 type programmable option select registers

1F0 - 1FF Hard Dist (AT)

200 - 20F Game/Control Port

210 - 21F Expansion Unit (XT)

238 - 23B Bus Mouse

23C - 23F Alternate Bus Mouse

278 - 27F Parallel printer

2B0 - 2BF EGA Display Port

2C0 - 2CF EGA Display Port (alt)

2D0 - 2DF EGA Display Port (alt)

2E0 - 2E7 GPIB (AT)

2E8 - 2EF Serial Port (COM4)

2F8 - 2FF Serial Port (COM2)

300 - 30F Prototype Card

310 - 31F Prototype Card

320 - 32F Hard Disk (XT)

378 - 37F Parallel Printer

380 - 38F SDL C

3A0 - 3AF SDL C

3B0 - 3BB MDA

3BC - 3BF Parallel Printer

3C0 - 3CF EGA

3D0 - 3DF CGA

3E8 - 3EF Serial Port (COM3)


3F0 - 3F7 Floppy Disk

3F8 - 3FF Serial Port (COM1)

If you are not sure about which address range is available on your PC, you may run the program "IOMAP.EXE" which is supplied on your SmartCard-8 distribution diskette. This program will give you a visual snapshot of the I/O space in the 100-3FFh range. You will then be able to determine which I/O addresses are in use by another device. When running the I/O map program, each dot on the screen represents an available byte of I/O. Colored or solid rectangles indicate I/O space which is currently in use by another device.

Jumper block JB4 selects one of seven base addresses for the SmartCard-8. See diagram below for the location of JB4.

NOTE: The I/O map will not function properly if you have a network card installed.



Location of JB4

In the following chart, "on" indicates that a jumper is installed between the two pins under the number indicated. "off" indicates that no jumper is installed. All three jumpers installed is not a valid selection.

Base Address	JB4-0	JB4-1	JB4-2
2E0H	OFF	OFF	OFF
2E4H	ON	OFF	OFF
210H	OFF	ON	OFF
214H	ON	ON	OFF
218H	OFF	OFF	ON
21CH	ON	OFF	ON
220H	OFF	ON	ON
ILLEGAL	ON	ON	ON

JB4 Addr:

0 1 2


<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Simply place a shorting jumper as indicated.

NOTE: you need only 2 jumpers to cover all possible selections, and you need NO jumpers to use the default selections

IRQ Selections


It is not necessary to use any interrupts with the SmartCard-8. However, if special interrupting functions are desired, IRQ selections are made with a SINGLE shorting jumper on jumper block JB3. Interrupts 2,3,5,10 & 12 may be selected. Location of JB3 is shown below.



Location of IRQ Select
Jumper (JB3)

IRQ: 12 10 5 3 2

JB3



Connecting the BBS Guardian Watchdog to the Motherboard.


A 2 conductor 15 inch cable is supplied with your GTEK product which is used to connect the watchdog circuit on the SmartCard to the reset circuitry on your computer. Follow the diagram to see how to install the watchdog circuit to your motherboard. Note that use of the Guardian Watchdog is NOT required in order to use the SmartCart-8.

RJ-45 on the upper rear of the SC-8




Connect your reset pushbutton here

Connect the provided jumper wire between here and where your reset pushbutton used to connect.



Physical Installation

After you have selected the base address and interrupt (if any) for your SmartCard-8, you may proceed with the physical installation of the card. You may wish to make a note of your current jumper settings for future use.



CAUTION

Be sure that the power switch on your computer is turned off and the power cord is removed from your computer before installing or removing any equipment.


Please refer to your computer's reference manual concerning the installation of expansion cards. If you are not familiar with the process of installing expansion cards in your computer or if you feel uncomfortable with this installation, refer the installation to qualified personnel. Failure to follow the instructions may result in damage to your compute, damage to the SmartCard or both.

Step 1 - Carefully remove the cover of your PC.

Case styles vary, so follow the instructions in your computer manual for removing the cover of your PC to expose the expansion slots.


Step 2 - Choose an available 8 or 16 bit expansion slot.

Eight bit slots will have only one card edge connector. 16 bit slots will have 2 card edge connectors. In order to access the higher (above IRQ7) interrupts, you will have to install your SmartCard in a 16 bit slot. You will need to remove the screw and bracket which covers the slot hole. Retain the screw for the



Top View of Computer


Step 3 - Carefully insert the SmartCard into the available slot and secure it in place with the screw that you removed in step 2.



SmartCard inserted into slot


Step 4 - insert cable retaining bracket.

If you will be using the two ports on the rear of the SmartCard (Ports 6 & 7), you may wish to use the cable retaining bracket supplied with the unit. The cable retaining bracket has 2 cutouts which secure the 2 cables which plug into ports 6 & 7.




Cable Retaining Bracket

The 2 cables for ports 6 & 7 can be identified by the rubber grommets which are installed approximately 10 inches from the RJ-45 plug.



RJ-45 cables with rubber grommets (2)

To install the cable retaining bracket, you must first remove an existing cover bracket and retain the screw. Locate the cables for ports 6 & 7. Carefully route the cables through the slot where you removed the existing cover.



RJ-45 cables routed through opening

Using G00

Before you may use your SmartCard with your BBS Software, you must load the G00 driver. The G00 program installs a FOSSIL driver on the SmartCard. It also loads a small TSR in your computer's memory which provides a link between the Software which sends and receives FOSSIL commands and the SmartCard. See below for G00 command line parameters.

USAGE EXAMPLES:

```
G00 u           ;uninstalls g00
G00 2e0         ;install board at 2e0 to com1-8
G00 2e0 w       ;install board at 2e0 with GUARDIAN
Watchdog.
G00 i,2e0,3     ;install board at 2e0 starting com3
                ;but no timer interrupt intercept.
                ;Allows fossil to be run in dos window
                ;which might be switched out to disk.
G00 2e0 2e4     ;installs two boards as com1-16
G00 2e0, 2e4, 5 ;installs boards starting at com5
G00 n, 2e0, 2e4 ;continues installation even if one
                ;board is missing or inoperative.
G00 2e0,2e4,2e8,2ec,1e0,1e4,1e8,1ec,3
                ;install as com3 to com67
```

Upon the successful installation of G00 you will see the following message:

Smartcard(tm) Fossil Driver - Copyright 1994, GTEK Inc.
Version 5.20B - November 17, 1994

Card Base Address - 0218H
BBS-8F O.S. Version - 232A
Loading Smartcard Fossil O.S.!
Smartcard Opsys Version - 300D

Smartcard ports begin with COM-01

OPTION W - Guardian Watchdog has been enabled.

Driver installed successfully.

Smarts program

Included with every Smartcard is a Status/control program which allows the user to view and/or modify currently installed FOSSIL parameters. See below for a list of available commands.

EXAMPLE USAGE:

smarts S	;all kinds of status
smarts W1 or W0	;turn on or off watchdog
smarts COM24:1200	;sets baud only
smarts COM1:38400,n,8,1	;set port parameters
smarts COM2:57600,e,7,1,L	;set and lock port
parameters	
smarts COM1:U	;unlock port parameters
smarts COM1:L	;lock port parameters
smarts COM7:C1 or C0	;cd is reflection of dtr.
smarts COM3:ON or OFF	;turn fossil on/off
smarts COM6:FT or FR or FB	;buffer flush tx ,rx, or both!

Examples of the Smarts program status screens:

Smartcard(tm) Status / Control Program

Copyright 1994, GTEK Inc.

Version 1.00A - November 11, 1994

GTEK Smart Fossil version - 5.20B

Receiver Buffer Sizes - 1024

Transmit Buffer Sizes - 2048

There are 08 Smart ports beginning with COM01

The Guardian(tm) Watchdog is ENABLED.

Port	Baud	P L S	Fossil	Locked	NRxChar	NTxChar	Modem Status/Cntl	Other
COM01:19200,N,8,1	OFF				0000	0000	dt rs	
COM02:19200,N,8,1	OFF				0000	0000		
COM03:57600,N,8,1	ON	LOCK			0000	0000	cs dt rs	
COM04:19200,N,8,1	OFF				0000	0000	cs	ctod
COM05:19200,N,8,1	OFF				0000	0000		
COM06:19200,N,8,1	OFF				0000	0000		
COM07:19200,N,8,1	OFF				0000	0000		
COM08:19200,N,8,1	OFF				0000	0000		

Note: CtoD set/cleared with smarts c1/c0, can be used to do hardwire connect with 6 conductor only. Causes sensed CD to be that of DTR. Thus only txd, rxd, rts, cts, and ground are necessary. Tie Cd to DTR at terminal end.

Smartcard(tm) Status / Control Program

Copyright 1994, GTEK Inc.

Version 1.00A - November 11, 1994

Port Parameters set and UN-locked.

Port Parameters Locked.

LIMITED WARRANTY

1 HARDWARE

GTEK, INC., warrants to the original purchaser of this GTEK, INC., product that it is to be in good working order for a period of one year from the date of purchase from GTEK, INC., or an authorized GTEK, INC., dealer. Should this product, in GTEK, INC.'s opinion, malfunction during the warranty period, GTEK will, at its option, repair or replace it at no charge, provided that the product has not been subjected to misuse, abuse, or non-GTEK authorized alterations, modifications, and / or repairs. Products requiring Limited Warranty service during the warranty period should be delivered to GTEK with proof of purchase. If the delivery is by mail, you agree to insure the product or assume the risk of loss or damage in transit. You also agree to prepay the shipping charges to GTEK.

All Express And Implied Warranties For This Product Including, But Not Limited To, The Warranties Of Merchantability And Fitness For A Particular Purpose, Are Limited In Duration To The Above 1 Year Period. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

Under No Circumstances Will GTEK, INC. Be Liable In Any Way To The User For Damages, Including Any Lost Profits, Lost Savings, Or Other Incidental Or Consequential Damages Arising Out Of The Use Of, Or Inability To Use, Such Product. Some states do not allow the exclusion or limitation of incidental or consequential damages for consumer products, so the above limitations or exclusion may not apply to you.

This Warranty Gives You Specific Legal Rights, And You May Also Have Other Rights Which May Vary From State To State.

The limited warranty applies to hardware products only.

2 SOFTWARE

This Product Is Not A Consumer Product Within The Meaning Of The Uniform Commercial Code And Applicable State Law. The Program Is Provided "AS IS" Without Warranty Of Any Kind, Either Expressed Or Implied, Including, But Not Limited To The Implied Warranties Of Merchantability And Fitness For A Particular Purpose. The Entire Risk As To The Quality And Performance Of The Program Is With You. Should The Program Prove Defective, You (Not GTEK, INC.) Assume The Entire Cost Of All Necessary Servicing, Repair Or Correction. Some States Do Not Allow The Exclusion Of Implied Warranties, So The Above Exclusion May Not Apply To You. This Warranty Gives You Specific Legal Rights And You May Also Have Other Rights Which Vary From State To State.

GTEK, Inc. does not warrant that the functions contained in the program will meet your requirements or that the operation of the program will be uninterrupted or error free. However, GTEK, Inc. warrants the diskette(s) on which the program is furnished, to be free from defects in materials and workmanship under normal use for a period of ninety (90) days from date of delivery to you as evidenced by a copy of your receipt.

Licensee herein acknowledges that the software licensed hereunder is of the class which inherently cannot be tested against all contingencies by Licensor. Licensee acknowledges Licensee's obligation to test all programs produced by the licensed software to determine suitability and correctness prior to use.

3 LIMITATIONS OF REMEDIES

GTEK, Inc.'s entire liability and your exclusive remedy shall be:

1.the replacement of any diskette(s) not meeting GTEK's "Limited Warranty" and which is returned to GTEK, Inc. with a copy of your receipt, or

2.if GTEK, Inc. or the dealer is unable to deliver a replacement diskette(s) which is free of defects in materials or workmanship, you may terminate this Agreement by returning the program and your money will be refunded.

In No Event Will GTEK, INC. Be Liable To You For Any Damages, Including Any Lost Profits, Lost Savings Or Other Incidental Or Consequential Damages Arising Out Of The Use Or Inability To Use Such Program Even If GTEK, INC. Has Been Advised Of The Possibility Of Such Damages, Or For Any Claim By Any Other Party.

Some States Do Not Allow The Limitation Or Exclusion Of Liability For Incidental Or Consequential

Damages So The Above Limitation Or Exclusion May Not Apply To You.

4 GENERAL

You may not substitute, assign or transfer the license or the program except as expressly provided in this Agreement. Any attempt otherwise to sublicense, assign or transfer any of the rights, duties or obligations hereunder is void.

This Agreement will be governed by the laws of the State of Mississippi.

Should you have any questions concerning this Agreement, you may contact GTEK, Inc. by writing to:

GTEK, Inc. Sales and Service
P. O. Box 2310
Bay St. Louis, MS 39521-2310

SERVICE

For warranty service or non warranty service, contact GTEK, INC. at (601) 467-8048 to obtain an RMA (Return of Material Authorization number).

We will need the serial number and date of purchase. Send the SmartCard freight prepaid to:

GTEK, INC.

RMA #####

399 Highway 90

Bay St. Louis, MS. 39520

Be sure to include the RMA number on and in the package so we will know what to do with it. Out of warranty service charges are determined on an hourly labor plus materials basis.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Information to user: The user is cautioned that changes or modifications not expressly approved by GTEK, Inc. could void the user's authority to operate the equipment.

SOFTWARE LICENSE AGREEMENT

"This software is a proprietary product of GTEK, INC. It is protected by copyright and trade secret laws. It is licensed (not sold) for use on a single microcomputer system, and is licensed only on the condition that you agree to this License Agreement." GTEK, INC. provides this program and licenses its use worldwide. You assume responsibility for the use of this software to achieve your intended results, and for the installation, use and results obtained from the software.

LICENSE

The Licensee may:

- a. use the program on a single machine;
- b. copy the program into any machine readable or printed form for backup or modification purposes in support of your use of the program on the single machine;
- c. modify the program and/or merge it into another program for your use on the single machine (Any portion of this program merged into another program will continue to be subject to the terms and conditions of this Agreement.); and,
- d. transfer the program and license to another party if the other party agrees to accept the terms and conditions of this Agreement. If you transfer the program, you must at the same time either transfer all copies whether in printed or machine readable form to the same party or destroy any copies not transferred; this includes all modifications and portions of the program contained or merged into other programs.

You must reproduce and include the copyright notice on any copy, modification or portion merged into another program.

You May Not Use, Copy, Modify, Or Transfer The Program, Or Any Copy, Modification Or Merged Portion, In Whole Or In Part, Except As Expressly Provided For In This License. If You Transfer Possession Of Any Copy, Modification Or Merged Portion Of The Program To Another Party, Your License Is Automatically Terminated.

TERM

The license is effective until terminated. You may terminate it at any other time by destroying the program together with all copies, modifications and merged portions in any form. It will also terminate upon conditions set forth elsewhere in this Agreement or if you fail to comply with any term or condition of this Agreement. You agree upon such termination to destroy the program with all copies, modifications and merged portions in any form.

FOSSIL functions supported by the SmartCard series

AH = 00h Set baud rate

Parameters:

Entry: AL = Baud rate code

DX = Port number

Exit: AX = Port status (see function 03h)

This works the same as the equivalent IBM PC BIOS call, except that it ONLY selects a baud rate. This is passed in the high order 3 bits of AL as follows:

010 = 300 baud

011 = 600 "

100 = 1200 "

101 = 2400 "

110 = 4800 "

111 = 9600 "

000 = 19200 " (Replaces old 110 baud mask)

001 = 38400 " (Replaces old 150 baud mask)

Bits 4-3 define parity:

0 0	no parity
1 0	no parity
0 1	odd parity
1 1	even parity

Bit 2 defines stop bits:

0	1 stop bit;
1	1.5 bits for 5-bit char;
2	for others

Bits 1-0 character length:

0 0	5 bits
0 1	6 bits
1 0	7 bits
1 1	8 bits

AH = 01h Transmit character with wait

Parameters:

Entry: AL = Character

DX = Port number

Exit: AX = Port status (see function 03h)

AL contains the character to be sent. If there is room in the transmit buffer the return will be immediate, otherwise it will wait until there is room to store the character in the transmit buffer. On return, AX is set as in a status request (see function 03h).

AH = 02h Receive character with wait

Parameters:

Entry: DX = Port number

Exit: AH = 00h

AL = Input character

If there is a character available in the receive buffer, returns with the next character in AL. It will wait until a character is received if none is available.

AH = 03h Request status

Parameters:

Entry: DX = Port number

Exit: AX = Status bit mask (see below)

Returns with the line and modem status in AX. Status bits returned are:

In AH:

Bit 0 = RDA - input data is available in buffer

Bit 1 = OVRN - the input buffer has been overrun. All characters received after the buffer is full should be discarded.

Bit 5 = THRE - room is available in output buffer

Bit 6 = TSRE - output buffer is empty

In AL:

Bit 3 = Always 1 (always return with this bit set to 1)

Bit 7 = DCD - carrier detect

This can be used by the application to determine whether carrier detect (CD) is set, signifying the presence/absence of a remote connection, as well as monitoring both the input and output buffer status. Bit 3 of AL is always returned set to enable programs to use it as a carrier detect bit on hardwired (null modem) links.

AH = 04h Initialize driver

Parameters:

Entry: DX = port number

BX = 4F50h

Exit: AX = 1954h if successful

BL = maximum function number supported
(not counting functions 7Eh and above)

BH = rev of FOSSIL doc supported

This is used to tell the driver to begin operations, and to check that the driver is installed. This function should be called before any other communications calls are made. At this point all interrupts involved in supporting the comm port (specified in DX) should be set up for handling by the FOSSIL, then enabled. DTR is raised by this call.

AH = 05h Deinitialize driver

Parameters:

Entry: DX = Port number

Exit: None

This is used to tell the driver that comm port operations are ended. The function should be called when no more comm port functions will be used on the port specified in DX. DTR is NOT affected by this call.

AH = 06h Raise/lower DTR

Parameters:

Entry: DX = Port number

AL = DTR state to be set (01h = Raise, 00h = Lower)

Exit: None

This function is used to control the DTR line to the modem. AL = 00h means lower DTR (disable the modem), and AL = 01h means to raise DTR (enable the modem).

AH = 07h Return timer tick parameters

Parameters:

Entry: None

This is used to determine the parameters of the timer tick on any given machine. Three numbers are returned:

AL = Timer tick interrupt number

AH = Ticks per second on interrupt number shown in AL

DX = Milliseconds per tick (approximate)

AH = 08h Flush output buffer

Parameters:

Entry: DX = Port number

Exit: None

This is used to force any pending output. It does not return until all pending output has been sent. You should use this call with care.

AH = 09h Purge output buffer

Parameters:

Entry: DX = Port number

Exit: None

This is used to purge any pending output. Any output data remaining in the output buffer (not transmitted yet) is discarded.

AH = 0Ah Purge input buffer

Parameters:

Entry: DX = Port number

Exit: None

This is used to purge any pending input. Any input data which is still in the buffer is discarded.

AH = 0Bh Transmit no wait

Parameters:

Entry: DX = Port number

Exit: AX = 0001h - Character was accepted
 = 0000h - Character was not accepted

This is exactly the same as the "regular" transmit call, except that if the driver is unable to buffer the character (the buffer is full), a value of 0000h is returned in AX. If the driver accepts the character (room is available), 0001h is returned in AX.

AH = 0Ch Non-destructive read-ahead

Parameters:

Entry: DX = Port number

Exit: AH = 00h - Character is
 AL = Next character available
 AX = FFFFh - Character is not available

Return in AL the next character in the receive buffer. If the receive buffer is empty, return FFFFh. The character returned remains in the receive buffer. Some applications call this "peek".

AH = 0Dh Keyboard read without wait

Parameters:

Entry: None

Exit: AX = IBM-style scan code (Character available)
 = FFFFh (Character not available)

Return in AX the next character (non-destructive read ahead) from the keyboard; if nothing is currently in the keyboard buffer, return FFFFh in AX. Use IBM-style function key mapping in the high order byte. Scan codes for non-"function" keys are not specifically required, but may be included. Function keys return 00h in AL and the "scan code" in AH.

AH = 0Eh Keyboard read with wait

Parameters:

Entry: None

Exit: AX = IBM-style scan code

Return in AX the next character from the keyboard; wait if no character is available.

AH = 0Fh Enable or disable flow control

Parameters:

Entry: AL = Bit mask describing requested flow control
 DX = Port number

Exit: None

TRANSMIT flow control allows the "other end" to restrain the transmitter when you are over-running it. RECEIVE flow control tells the FOSSIL to attempt to do just that if it is being overwhelmed.

Bit 1 = 1 CTS/RTS (CTS on transmit, RTS on receive)

Flow control is enabled, or disabled, by setting the appropriate bits in AL for the types of flow control we want to ENABLE (value = 1), and/or DISABLE (value = 0), and calling this function.

Enabling CTS/RTS will cause the FOSSIL to cease transmitting when CTS is lowered. Transmission will resume when CTS is raised. The FOSSIL will drop RTS when the receive buffer reaches a predetermined percentage full. The FOSSIL will raise RTS when the receive buffer empties below the predetermined percentage full.

AH = 10h Extended Control-C / Control-K checking and transmit on/off

Parameters:

Entry: AL = Bit mask (see below)

DX = Port number

Exit: AX = 0001h - Control-C/K has been received

 = 0000h - Control-C/K has not been received

This is used for BBS operation, primarily. A bit mask is passed in AL with the following flags:

Bit 0 Enable/disable Control-C / Control-K checking

Bit 1 Disable/enable the transmitter

The Enable (bit 0 = 1) and Disable (Bit 0 = 0) Control-C/Control-K check function is meant primarily for BBS use. When the checking is enabled, the FOSSIL peeks at the last character received and checks for Control-C / Control-K.

The Disable (Bit 1 = 1) and Enable (Bit 1 = 0) Transmitter function lets the application restrain the asynchronous driver from output in much the same way as XON/XOFF would.

AH = 11h Set current cursor location.

Parameters:

Entry: DH = Row (line)

DL = Column

Exit: None

This function looks exactly like like INT 10h, subfunction 2, on the IBM PC. The cursor location is passed in DX: row in DH and column in DL. The function treats the screen as a coordinate system whose origin (0,0) is the upper left hand corner of the screen.

AH = 12h Read current cursor location.

Parameters:

Entry: None

Exit: DH = Row (line)

DL = Column

Looks exactly like INT 10h, subfunction 3, on the IBM PC. The current cursor location (using the same coordinate system as function 16h) is passed back in DX.

int	14
cmp	ax,0
jz	succeeded

AH = 15h Write character to screen using BIOS support routines

Parameters:

Entry: AL = Character to display

Exit: None

The character in AL is sent to the screen using BIOS-level Input/Output routines. This differs from function 13h in that DOS I/O CAN NOT be used, as this function might be called from driver level.

AH = 16h Insert or delete a function from the timer tick chain

Parameter:

Entry: AL = 01h - Add a function

 = 00h - Delete a function

 ES = Segment of function

 DX = Offset of function

Exit: AX = 0000h - Operation successful

 = FFFFh - Operation unsuccessful

This function is used to allow a central authority to manage the timer interrupts, so that as code is loaded and unloaded, the integrity of the "chain" is not compromised. Rather than using the traditional method of saving the old contents of the timer vector, storing the address of your routine there, and executing a far call to the "old" routine when yours is done, instead you call this function. It manages a list of such entry points and calls them on a timer tick (interrupt) using a FAR call.

AH = 17h Reboot system

Parameters:

Entry: AL = 00h - "Cold boot"

 = 01h - "Warm boot"

AH = 18h Read block (transfer from FOSSIL to user buffer)

Parameters:

Entry: CX = Maximum number of characters to transfer

 DX = Port number

 ES = Segment of user buffer

 DI = Offset into ES of user buffer

Exit: AX = Number of characters actually transferred

A "no-wait" block read of 0 to FFFFh characters from the FOSSIL inbound ring buffer to the calling routine's buffer. ES:DI are left unchanged by the call; the count of bytes actually transferred will be returned in AX.

AH = 19h Write block (transfer from user buffer to FOSSIL)

Parameters:

Entry: CX = Maximum number of characters to transfer

DX = Port number

ES = Segment of user buffer

DI = Offset into ES of user buffer

Exit: AX = Number of characters actually transferred

A "no-wait" block move of 0 to FFFFh characters from the calling program's buffer into the FOSSIL outbound ring buffer. ES:DI are left unchanged by the call, the count of bytes actually transferred will be returned in AX.

AH = 1Ah Break begin or end

Parameters:

Entry: AL = 01h - Start sending 'break'

= 00h - Stop sending 'break'

DX = port number

Exit: None

Send a break signal to the modem. If AL=01h the driver will commence the transmission of a break. If AL=00h the driver will end the break. This is useful for communications with devices that can only go into command mode' when a BREAK is received. Note: the application is responsible for the timing of the BREAK. Also, if the FOSSIL has been restrained by an Xoff received from the modem, the flag will be cleared. An Init or Un-Init will stop an in-progress BREAK.

AH = 1Bh Return information about the driver

Parameters:

Entry: CX = Size of user info buffer in bytes

DX = Port number

ES = Segment of user info buffer
 DI = Offset into ES of user info buffer
 Exit: AX = Number of bytes actually transferred

Transfer information about the driver and its current status to the user
 for use in determining, at the application level, limits of the driver.
 The data structure currently returned by the driver is as follows (sorry



```

info          equ    $           ; define begin of structure
strsiz        dw     info_size    ; size of the structure in bytes
majver        db     curr_fossil  ; FOSSIL spec driver conforms to
minver        db     curr_rev     ; rev level of this specific driver
ident         dd     id_string    ; "FAR" pointer to ASCII ID string
ibufr         dw     ibsize       ; size of the input buffer (bytes)
ifree         dw     ?            ; amount of unfilled buffer
obufr         dw     obsize       ; size of the output buffer (bytes)
ofree         dw     ?            ; amount of unfilled buffer -1
swidth        db     screen_width ; width of screen on this adapter
sheight       db     screen_height ; height of screen " "
baud          db     ?            ; ACTUAL baud rate, computer to modem
info_size     equ    $-info


```

The baud rate byte contains the bits that Function 00h would use to set the port to that speed. The fields related to a particular port (buffer size, space left in the buffer, baud rate) will be undefined if port FFh or an invalid port is contained in DX.

Gtek Card



To 90-Connector



Channel 0	Channel 1	Channel 2	Channel 3	Channel 4	Channel 5	Channel 6	Channel 7	Channel 8	Channel 9	Channel 10
A1	A1	A1	A1	A1	A1	A1	A1	A1	A1	A1
B1	B1	B1	B1	B1	B1	B1	B1	B1	B1	B1
C1	C1	C1	C1	C1	C1	C1	C1	C1	C1	C1
D1	D1	D1	D1	D1	D1	D1	D1	D1	D1	D1
E1	E1	E1	E1	E1	E1	E1	E1	E1	E1	E1
F1	F1	F1	F1	F1	F1	F1	F1	F1	F1	F1
G1	G1	G1	G1	G1	G1	G1	G1	G1	G1	G1
H1	H1	H1	H1	H1	H1	H1	H1	H1	H1	H1
I1	I1	I1	I1	I1	I1	I1	I1	I1	I1	I1

(Note: On BUS-150 and SMARTCARD-B channels 16 and 17 are open (shown) compared to these 6.)

Channel 16 and 17 require cables that have a cable connector on them bracket on the back of the computer

This view is looking at the solder side of the PC board. The RJ-45 (10 connection) is inserted with the long the PC board. This makes the pins at the top to be 110 as shown.

Warning: Don't expect the WIRE COLORS to always be the same from one cable to another!

Copyright 1993, Gtek, Inc.

SUGGESTED DTE WIRING

Wiring Male conn. with DTE cards. (DTE)

Size Document Number

A 8018.sch

REV

DATE: FEBRUARY 20, 1993 Sheet 91



Development Hardware and Software

P. O. Box 2310

399 Highway 90

Bay St. Louis, MS 39521-2310 USA

(228) 467-8048